

RAID- RAID

RAID


 Image not found or type unknown

RAID RAID

2. RAID

1. “Adapter Properties” “RAID Properties”
- “Enter” “Select New Volume Type”[6-48 Select New Volume Type](#)
- 6-48Select New Volume Type

 Image not found or type unknown




2. “Select New Volume Type” “View Existing Volume”

“Enter” “View Volume” 6-49 View Volume

6-49View Volume

Image not found or type unknown




3. “Manage Volume” “Enter”

“Manage Volume”

6-50Manage Volume

Image not found or type unknown



4. "Delete Volume" "Enter"
"Delete Volume"

 Image not found or type unknown

RAID

- 5.

- "Y"

[RAID-10 Adapter Properties](#)

- "N"

[RAID-10 Manage Volume](#)

Revision #1

Created 18 June 2022 15:03:42 by

Updated 9 July 2022 19:32:46 by