(DDNS)

1.


ASUSTOR NAS ASUSTOR NAS DDNS

1.1 IP

IP IP

1.2 IP


IP DDNS ASUSTOR NAS DDNS "no-ip" IP DDNS IP



2.
ASUSTOR NAS

2.1 Web ()

1
a. []-*Web [][]]



b. NAS IP

asustor

Congratulations!



You have successfully enabled the Web server on your ASUST


To begin hosting your website on the NAS, simply upload your web pages to the [Web] shared folder.

Copyright ©

c. ASUSTOR NAS [Web]

2

[[]]



3

" []'

lost name:	ASUSTOR.hopto.org			
Folder name:	/Web		Browse	
Protocol:	НТТР	~	555	
Port number:	80	\$		
Status:	Enable		O Disable	

2.2 DDNS Enabling DDNS service

DDNS NAS NAS DDNS

1

a. []-***** [**DDNS**]

b. [**DDNS**]

c. DDNS DDNS []

d. [NAS DDNS

Revision #1 Created 8 March 2022 07:22:43 by Updated 9 July 2022 19:11:06 by